



PRODUCT IMAGE SHOWN IS FOR ILLUSTRATIVE PURPOSES ONLY, SHOULD NOT BE TAKEN AS REFERENCE POINT

INSTRUCTIONS:

- 1.- ATTACH THE RAIL TO THE HEADBOARD AND FOOTBOARD BY INSERTING THE BED HARDWARE (HOOK) OF THE RAIL INTO THE SLOTS AND PUSHING DOWN THE RAIL UNTIL IT IS COMPLETELY TIGHT.
- 2.- AFTER ATTACHING THE RAILS, SCREW THE LEGS TO THE SLAT SUPPORT AND THEN PLACE THE SLATS SUPPORT BETWEEN THE RAILS.

HARDWARE

DESCRIPTION	PCS
FLAT HEAD SCREW 8 X 3/4"	8



ASSEMBLY INSTRUCTIONS

I-MIX-C004