



INSTRUCTIONS:

- 1.- ATTACH THE RAILS INSERTING THE SOCKET HEAD BOLT THROUGH THE RAIL AND INTO THE PERFORATIONS IN THE HEADBOARD AND FOOTBOARD AS SHOWN.
- 2.- SCREW THE CENTER LEGS TO THE SLAT SUPPORT.

NOTE: THE HARDWARE IS LOCATED IN THE HEADBOARD AND FOOTBOARD.

HARDWARE	
DESCRIPTION	#PCS
ALLEN KEY 3/16"	1

PRODUCT IMAGE SHOWN IS FOR ILLUSTRATIVE PURPOSES ONLY, SHOULD NOT BE TAKEN AS REFERENCE POINT



ASSEMBLY INSTRUCTIONS

I-MIX-C016