



INSTRUCTIONS

- 1.- WITH HELP TURN FACE BACK THE TOP IN A CLEAN SURFACE.
- 2.- PLACE THE LEGS ALIGNING HOLES WITH THE TOP AND SCREW THEM AS SHOW IN DRAWING.
- 3.- ASK FOR HELP TO TURN THE TABLE IN ITS RIGHT POSITION.

HARDWARE	
DESCRIPTION	# PCS
HEX SOCKET BUTTON HEAD BOLT 5/16 X 1-1/2"	8
WASHER 5/16"	8
LOCK WASHER 5/16"	8
ALLEN KEY 3/16"	1

PRODUCT IMAGE SHOWN IS FOR ILLUSTRATIVE PURPOSES ONLY, SHOULD NOT BE TAKEN AS REFERENCE POINT



ASSEMBLY INSTRUCTIONS

I-TBL-C010